


## CANTYVISION WEB STREAMS


CANTY cameras used for analysis must be directly connected to a Vector Control Module (VCM) to support the gigabit Ethernet connection. Occasionally, our customers want to be able to send out a live stream of the camera video over their network for others to view. This can be accomplished using CantyVision Web Streams from select analytical software!

Applications	Roles	Summary	Authentication	HTTPS	Remote	Control	3	
Installed certificate No certificate is installed.								
HTTPS settings: O Use a certificate from a certification authority O Use a self-signed certificate (less secure)								
Disable HTTPS (insecure) Disabling HTTPS causes all communication with the web server to be sent unsecured. Some web features may require HTTPS be enabled.								
Server HTTP port								
				Apply ar	nd restart	Rev	/ert	

User-configurable web server allows streams to be set up as HTTP, HTTPS using a self-signed certificate, or HTTPS using a certificate from a certification authority.

Software settings allow for adjusting image quality and resolution which impacts the amount of data the stream uses.





Web streams are available to access as JPEG and MJPEG.

	JPEG Stream	MJPEG Stream
Max Frame Rate	5	10
Max # Streams per camera	Unlimited	2